


# RM2599 41ADPS1C983

Contact Us at: [www.PartsFor.com](http://www.PartsFor.com) for Replacement Parts.




Item	Part No.	Description
1	753-06194	Rear Cover Assembly (includes 2 & 3)
2	791-181862	Housing Screw
3	791-181345	Cover Screw
4	753-06174	O-Ring
5	753-06175	Flywheel Assembly
6	753-06247	Washer
7	753-06218	Spacer
8	753-06943	Starter Housing (includes 3 & 12)
9	753-05860	Clutch Assembly
10	753-06181	Clutch Cover (includes 2)
11	753-06418	Muffler Assembly
12	791-182366	U-shaped Nut
13	753-06921	Fuel Tank Assembly (includes 14 & 15)
14	791-181930	Tank Screw
15	791-182612	Fuel Cap
16	753-06826	Module Assembly

Item	Part No.	Description
17	753-06847	Spark Plug
18	791-182723	Crankcase Bolt
19	753-06275	Crankcase O-Ring
20	753-06189	Insulator Assembly (includes 21 & 22)
21	753-06184	Insulator O-Ring
22	753-06185	Carburetor O-Ring
23	753-06190	Carburetor
24	753-06415	Aircleaner Cover Assembly (includes 25)
25	753-06417	Aircleaner Filter
26	753-06188	Throttle Cable
27	753-06187	Lead Wires
28	791-182519	Anti-rotation Screw
29	753-04003	Clamp Screw
30	791-180217	Clamp Nut
31	753-06253	Air Cleaner Gasket
32	753-08167	Short Block Assembly (includes 4 - 7 & 16 - 19)

# RM2599 41ADPS1C983

Contact Us at: [www.PartsFor.com](http://www.PartsFor.com) for Replacement Parts.



Item	Part No.	Description
1	753-04344	Upper Drive Shaft Housing Assembly
2	753-04234	Throttle Housing Assembly (includes 3 - 6)
3	791-182405	Throttle Switch Assembly
5	753-05171	Throttle Trigger Lock-Out
5	753-05517	Throttle Trigger
6	753-05007	Throttle Trigger Spring
7	753-06039	D-Handle (includes 9)
8	753-06040	D-Handle Bolt
9	753-06944	Split Boom Coupler Assembly (includes 10)
10	791-182057	Split Boom Coupler Screw
11	753-04352	Extension Boom
12	753-05724	Lower Drive Shaft Housing (includes 13)
13	791-181852	Flexible Drive Shaft
14	791-180288	Lower Drive Shaft Screw
15	753-05595	Sprocket Assembly
16	753-05599	Gearbox Assembly (includes 15 & 17)

Item	Part No.	Description
17	753-05589	Gearbox Screw
18	753-05596	Gearbox Bolts
19	753-05586	Oil Tank Assembly
20	753-05587	Fuel Cap Assembly
21	791-181345	Oil Tank Assembly Screws
22	753-05588	Oil Line
23	753-05597	Chain Tension Hardware Assembly
24	753-05594	Chainsaw Guide Bar
25	753-05592	Chain
26	753-05765	Chain Guard
27	791-181345	Chain Guard Screw
28	753-05591	Gearbox Nuts
29	753-05598	Chain Cover

\* Optional  
 \* 791-612605 Hanger